



installation guide

Furniture - Niche

BEFORE YOU BEGIN

Your choice is a testimonial to your excellent taste. Thank you for choosing from among WETSTYLE's quality line of products. We recommend that you carefully read this guide to ensure your niche's proper installation and reliability for many years to come.

TOOLS AND EQUIPMENT



Protective glasses



Drill and bits



Measuring tape



Paper pencil



Level

Putting up the wall-mounted niche:

1. Determine area and position of niche on the wall. Using a pencil, mark the centre of the niche and draw vertical and horizontal guidelines.

CLEANING GUIDE

The WETSTYLE Niches are made from rift-cut oak veneer, on high density select fiberboard and available in natural, wenge, white-washed or grey-washed shades. To ensure that the wood is waterproof, it is sealed with catalyzed varnish, a coating normally used for the decks of boats.

The WETSTYLE Niche is ultra-easy to clean: after each use, simply wipe with a soft cloth after each use, to remove any surface dirt. For standard cleaning, we recommend using warm water with vinegar.

Do not use abrasive products or cream cleansers. Never use petroleum-based products when cleaning, i.e. paint thinners or other solvents, as they may damage the wood surface.

WARRANTY

The warranty on WETSTYLE products covers all defects in materials and manufacturing for a period of one year from the date on which the owner originally purchased the product directly from WETSTYLE or from an authorized retailer. This warranty is valid for the original owner only.

This warranty does not apply to cases in which a product was incorrectly installed, nor to damage due to negligence, misuse, cigarettes, flames, natural catastrophes or other accidents.

WETSTYLE is not responsible for costs and claims that may arise from purchase of a product unsuited to the structure of the existing building.

Any transformation or alteration made to a WETSTYLE product automatically voids the warranty.

The manufacturer's warranty is limited to repair or replacement (with a product of equal value), provided the claim is made to an authorized retailer or directly to WETSTYLE within the warranty period. Labour costs and any other expenses entailed by replacement of a WETSTYLE product are not covered by the warranty.



www.WETSTYLE.CA - Montreal - Canada
Tel. 450.536.9000 - 1 888.536.9001 - Fax. 450.536.0202

S T Y L E